

Mechanical Fasteners Guide



1. Inspect your walls for loose studs. You will be able to hear the difference. We have several options to secure the wall. There are three recessed attachment points on each stud face.



2. At times mechanical fastening may be required. Use 3-1/4" Tapcon® screws.



3. Gripcon® nails. The nail installation is easier than the screw installation.

Mechanical Fasteners Guide



4. Here we will demonstrate installing a Perma-grip® nail. Use a Standard Hammer drill or Rotary Hammer drill to pilot a hole into the concrete wall.



5. Make sure you drill $\frac{1}{4}$ " deeper than the nail is long..



6. Use a hammer to drive the nail into the wall. Don't overdrive the nail. Tap the Perma-grip® fastener until securely seated.