

If the side wall and end wall panels are installed BEFORE the Corner Post Inserts, you must leave enough space for the corner post insert and a gap to fill with spray foam.

## Measurement along End Wall



From the corner pocket, measure out 8-1/2" along the end wall. This is where the end wall panels should start.

## Measurement along Side Wall



From the corner pocket, measure out 9" along the side wall. This is where the side wall panels should start.