Product Report No. 06090

TAPCON The Original Masonry Fastening System

The original masonry anchor that cuts threads into concrete, brick or hollow block.

Advanced Threadform Technology" Easier to installless torque required!

Applications

- Electrical junction boxes and conduit clips to masonry.
 - Wood headers and furring strips to masonry.

Product Features

- Fast installation ... drill a hole ... drive an anchor.
- Packaged with one Tapcon "close tolerance" masonry drill bit per 100 anchors. Also available in bulk packaging.
- Available in 3/16" diameter up to 4" in length and 1/4" diameter up to 6" in length.
- Compatible for use in ACQ treated wood.
- Replaces small diameter expansion anchors, plugs and screws in light to medium duty applications.
- No need to pre-spot holes ... and no inserts are required.
- Reversible and removable ... can be installed close to an edge.

Approvals and Listings

Miami Dade County Product Control Approved

- HVAC strapping to masonry.
- Plywood backer boards to masonry.
- Exterior insulation systems to masonry.

Installation Tools

NEW

DESIGN!

- Condrive 500° Compact high speed installation tool designed for installation of Tapcon hex head and Phillips flat head anchors up to 3-3/4" long.
- Condrive 1000° A multi-purpose tool designed for installation of Tapcon hex head and Phillips flat head anchors up to 3-3/4" long.
- Buildex Condrive Tools are designed to specifically install Tapcon Anchors and to fit standard hammer drills.



City of Los Angeles RR25644

Product Specifications

Diameter 3/16" and 1/4"

Thread Form..... Original notched Hi-Lo®

Point Type Nail

Finish Blue Climaseal®

Head Styles

3/16" Diameter:1/4" slotted hex washer head (HWH) (1/4" Diameter: 5/16" slotted hex washer head (HWH)

3/16" Diameter: #2 phillips flat head (PFH) 1/4" Diameter: #3 phillips flat head (PFH)

</



IE ORIGINAL TAPCON[®] MASONRY FASTENING SYSTEM

Selector Guide

Part Number		Description	Drill Bit	Part	Fixture	Common Applications		
PFH	HWH			Number	Thickness			
3169407	3139407	3/16 x 1-1/4"	5/32 x 3-1/2"	3095910	0 - 1/4"	•Mounting brackets; control panels; cable clamps, conduit clips, junction switch and control boxes.		
3183407	3153407	1/4 x 1-1/4"	3/16 x 3-1/2"	3098910	0 - 1/4"			
3171407	3141407	3/16 x 1-3/4"	5/32 x 3-1/2"	3095910	1/ - 3/4"	•1/2" or 3/4" plywood backer boards; mounting brackets; control panels; cable		
3185407	3155407	1/4 x 1-3/4"	3/16 x 3-1/2"	3098910	1/4 - 3/4"	clamps; conduit clips, junction, switch and control box meters.		
3173407	3143407	3/16 x 2-1/4"	5/32 x 4-1/2"	3096910	3/4" - 1-1/4"	+1 x 2 wood furring; 3/4" plywood backer boards; metal safety grating.		
3187407	3157407	1/4 x 2-1/4"	3/16 x 4-1/2"	3099910	3/4" - 1-1/4"			
3175407	3145407	3/16 x 2-3/4"	5/32 x 4-1/2"	3096910	1-1/4" - 1-3/4"	•2 x 4 wood nailers		
3189407	3159407	1/4 x 2-3/4"	3/16 x 4-1/2"	3099910	1-1/4" - 1-3/4"			
3177407	3147407	3/16 x 3-1/4"	5/32 x 5-1/2"	3097910	1-3/4" - 2-1/4"	•Sill plates; 2 pieces of 2 x 4 or 2 x 6 to masonry. Insulation to masonry.		
3191407	3161407	1/4 x 3-1/4"	3/16 x 5-1/2"	3100910	1-3/4" - 2-1/4"			
3179407	3149407	3/16 x 3-3/4"	5/32 x 5-1/2"	3097910	2-1/4" - 2-3/4"			
3193407	3163407	1/4 x 3-3/4"	3/16 x 5-1/2"	3100910	2-1/4" - 2-3/4"			
3181407	3151407	3/16 x 4"	5/32 x 5-1/2"	3097910	2-1/2" - 3"			
3195407	3165407	1/4 x 4"	3/16 x 5-1/2"	3100910	2-1/2" - 3"			
3197407	3167407	1/4 x 5"	3/16 x 6-1/2"	3102910	3-1/4" - 4"			
3203407	3205407	1/4 x 6"	3/16 x 7-1/2"	3206910	4-1/4" - 5"			
3379910		Condrive 500®	For 3/16 and 1/4	s up to 3-3/4"				
3103910		Condrive 1000®						
One drill bit	is provided wi	requirement is 1" an th every box of 100 p 5/32" x 7" SDS F	pieces.	Tapcon Anchors must be installed using all Buildex system components (Tapcon Anchors, Condrive Tools and Tapcon Drill Bits) in order to gualify for ITW Buildew system support				

(*Condrive 1000 Only)

3/16" x 7" SDS Rotary Hammer Drill Bit, Part Number 3101910.

Drill Bits) in order to qualify for ITW Buildex system support.

Performance Data

Tension in Normal-weight Concrete (lbs.)										
Anchor	Embedment	Concrete Strength								
Diameter	Depth	2000 psi	4000 psi	5000 psi						
	1″	600	650	800						
3/16″	1-1/2″	1090	1090	1220						
	1-3/4″	1450	1460	1730						
	1″	750	800	950						
1/4″	1-1/2″	1380	1820	2170						
	1-3/4″	2020	2380	2770						
Shear in Normal-weight Concrete (lbs.)										
Anchor	Embedment	Concrete Strength								
Diameter	Depth	2000 psi	4000 psi	5000 psi						
	1″	720	720	860						
3/16″	1-1/2″	860	860	860						
	1-3/4″	870	990	990						
	1″	900	1360	1440						
1/4″	1″ 1-1/2″	900 1200	1360 1380	1440 1670						
1/4″										
	1-1/2″	1200 1670	1380 1670	1670 1670						
Ter	1-1/2″ 1-3/4″	1200 1670 ar in CMU (1	1380 1670	1670 1670 1670						
	1-1/2" 1-3/4" Ision and She	1200 1670 ar in CMU (1	1380 1670	1670 1670 1670						

500 For minimum edge distance and spacing distance, please refer to the ICC-ES report or Miami-Dade report for this product. Lightweight and mediumweight Concrete Masonry Units (CMU) were defined by ASTM C 90.

620

1000

250

1/4"

1349 West Bryn Mawr Avenue Itasca, Illinois 60143 630-595-3500 Fax: 630-595-3549 www.itwbuildex.com

Installation Guidelines:

CONDRIVE 500 GUIDELINES:

- STEP 1: Place drill adapter into 3/8" or 1/2" chuck of standard hammer drill. Place drill bit in drill adapter and tighten set screw. Drill hole a minimum of 1/4" deeper than Tapcon anchor is to be embedded.
- STEP 2: Phillips Heads may be installed using either side of sleeve. To install a 1/4 diameter Hex Washer Head Tapcon, use large opening side of sleeve (see sleeve label). To install a 3/16 diameter Hex Washer Head Tapcon, use small opening side of sleeve (see sleeve label). Slide opposite side of sleeve over drill bit and snap onto drill bit adapter. NOTE: If driving Hex Washer Head Tapcon, driver will automatically disengage. If driving Phillips Head Tapcon, care must be taken to ensure anchor is not overdriven.
- STEP 3: Loosen set screw on side of drill adapter with 1/8" Hex Key. Do not remove completely. Replace old drill bit with new one. Align flat side with set screw and tighten screw. Do not overtighten.

CONDRIVE 1000 GUIDELINES:

- STEP 1: Place correct drill bit into driver adapter and drill hole 1/4" deeper than depth of embedment.
- STEP 2: Slide Condrive Installation Tool sleeve over drill bit. Snap hex head or Phillips Socket in place.
- STEP 3: Insert anchor in socket, position fixture to be fastened, begin to drive Tapcon into pre-drilled hole.
- STEP 4: The anchor is fully set when the nosepiece of the Condrive Tool automatically disengages from the socket and fixture is secured in place.

Note: Indicated tension and shear failure values were obtained in tests conducted at CEL Consulting. Designated holding power depends on the quality of the masonry material, depth of embedment and proper hole size. These figures are offered only as a guide and are not guaranteed in any way by Illinois Tool Works Inc. The figures indicate average ultimate tension and shear failure values. A safety factor of 4:1 or 25% of ultimate value is generally accepted as a safe working load. However, reference should always be made to applicable codes for the specific safe working ratio. All values are based on close tolerance holes drilled with Buildex Tapcon® carbide drill bits. Performance of the Tapcon anchor may vary in extremely hard concrete aggregates. Consult your Buildex representative for further information.

As in the case with all applications, Buildex can only suggest typical fasteners for typical applications and that the connection design is the sole responsibility of the Building Design Engineer, Architect or otherwise responsible person charged with the design of the connection. For further product information, please contact the nearest Authorized Buildex Distributor or the Buildex Technical Service Department at 1-800-323-0720.